insect pet part3

operating instructions

*Please remove the insulating tag first.

1. When you turn on the power, eggs will appear, and after 1 minute, larvae will hatch.
2. After 2 hours, the larva will turn into a pupa, and at this point you will know whether your insect pet is a rhinoceros beetle or a stag beetle.
3. After another two hours, the pupa will transform into an adult. What it becomes is a surprise! Once it becomes an adult, it will be able to battle other insect pets.

When you press the A button on the normal screen (the screen where the insect pet is moving) You will be taken to the action selection screen. Simply press the A button to select an action (the icon will change each time you press it), and then press the B button to confirm.

Please proceed. You can cancel with the C button.

Basic operations How to use buttons

A selection button
- Action selection
- Select action arrow (→)

B Confirm button
- Decide on an action; press again to start the action.

C cancel button
- Cancel action -
Return to previous screen

Fight button
- Versus Mode
- Roll/Stop the Dice

RESET Reset button
- Reset the game

*Pressing the RESET button will return the game to its initial state. Please be careful not to press it by mistake. When pressing, use a thin object and press lightly. Pressing too hard may cause damage.

Meal
There are three types of food: leaves, fruits, and tree sap. Each time you eat, your weight increases by 10 grams.

Each time you press A, the arrow's direction changes.
Press B to confirm.

·training
My insect pet does strength training.

karaoke
There are four songs.
Let's have fun singing them!

dance
Let's dance with our insect pets.

light
Turn off the lights when your insect pet falls asleep.

Each time you press A, the arrow's direction changes. Press B to confirm.

When the character is sleeping, "Zzz" will be displayed.

Cleaning
If your insect pet poops, clean it up for them.

hospital
If your pet insect gets sick, take it to the vet for an injection.

situation
Each time you press A, the displayed age, weight, and name will change.

number of wins
Find out how many you won.

number of losses
You can see how many you lost.

How to name
You can name it on the "NAME" screen.

*You can only name (change) the insect while it is in the larval and pupal stages. You cannot change its name once it becomes an adult.

1. You can enter up to 5 characters in order from the first character.

Each time you press A, the letters change sequentially, and press B to confirm and move to the next letter.
(If you keep pressing A, the characters will change faster.)
"Kya," "Kyu," and "Kyo" are also treated as single characters.
The space (blank space) is at the very end.
After entering up to the 5th character, press C to return to the previous screen.

situation

My pet insect has gotten sick. It can be cured with an injection at the vet. It might hurt a little...

"My insect pet has pooped. Please clean it up."

My insect pet is sleeping soundly.

Your insect pet has fallen asleep while still defecating (and is still sick). You cannot feed or clean its cage while it is sleeping. Please wait until your insect pet wakes up to do so.

Unfortunately, your insect pet has died. Press the RESET button to reincarnate it.

Character Introduction (All 12 types)


beetle


Caucasus beetle


Elephant beetle

Hercules beetle

Grant's White Beetle


Five-horned rhinoceros beetle


giant stag beetle


Mengata stag beetle


Rainbow stag beetle


Giraffa


saw


Zebra saw

Match safe

Let's battle against Tomodachi no Insect Pet part 3!!

1: You can only battle them once they become adults. Let's raise them first.

2: Align the red parts on the heads.

3: Press the F button on both sides to enter versus mode!!

4: Press the F button to spin the dice, and press it again to stop them.

In battle mode, tilt your insect pet 45 degrees as shown in the diagram on the right.

Communication takes place via the red area on the back of the device.



rule

- You start with 5 health points, and you lose when your health reaches 0.
- Both players roll the dice, and the one with the higher number attacks!!
- If the numbers are the same, it's a "DRAW" and neither counts.
- The person being attacked loses stamina equal to the difference in the number of eyes. A for example···

Person A's eyes show "6", and Person B's eyes show "1".

In this case, player B loses all 5 of their health points from player A's attack.

The result was a win for person A and a loss for person B.

When you roll a "6", it's a chance for a one-hit kill!!

You get a maximum of 5 dice rolls. If the game isn't decided by then, the player with more stamina remaining wins!

Screen display during battle

You are now in versus mode.

The black par to the right of the character is the remaining

Shows physical strength.

It gets shorter each time you take damage.

"The system is in a "waiting for communication" state.

Both insect pets

This indicates that communication is working correctly.

I'm attacking.

We are under attack.

‼ Important notice regarding Versus Mode ‼

*If the insect pets are more than 5cm apart, communication may not occur. *If neither player takes any action for 30 seconds, or if communication is lost, That match will be cancelled.

10勝すると「ニホンチャンピオン」!!

Win 20 matches and you'll become the "World Champion"!!

Become the world champion and you've cleared the game!!

Let's raise some new insects!! Big Sister



Losing 10 times means game over...

Becoming the Japanese champion resets your losses to 0!!

Product material

Body: ABS
Button: Synthetic rubber
Ball chain: iron
Mount: paper
Transparent cover: PET

Precautions for use

Target age 6 years and over

- To prevent damage, deformation, or malfunction, do not subject the product to strong impacts such as dropping it, apply excessive force, bring it near magnets or magnetic fields, or disassemble it. Also, avoid high or low temperatures.
- Do not use or store in places where it may be exposed to sunlight.
- The batteries that are pre-installed are for testing purposes only, so the screen display may be dim or the sound may be quiet. Please replace it when it happens. The leg parts are fixed to the battery cover. When replacing the battery... "Please remove the cover while the legs are still attached. Forcing the legs off may cause damage."
- Avoid using this product in places where it may be exposed to rain or water.

!Notice(caution)

Please be sure to read this for parents/guardians

- This toy contains small parts. Do not put them in your mouth. There is a risk of choking.
- There is a risk of accidental ingestion, so please do not give this to children under 3 years old.
- This device uses a button battery (LR44). Battery replacement must be performed by a parent or guardian.
- Please be aware that improper use of batteries may cause them to rupture, overheat, or leak.
- If swallowed, consult a doctor immediately.
- For safety reasons, do not use the product if it is damaged or deformed.
- Please refrain from rough play such as hitting or swinging the toy around.

*Please note that we cannot provide support for malfunctions other than initial defects.

Product liability insurance is included.

Design registration No. 1237308

Distributed by: Diamond Inc.

1-9-18 Minamihanahata, Adachi-ku, Tokyo 121-0062

TEL：03-3884-6919

MADE IN CHINA